

PRIOR TO INSTALLATION:

- OPEN and thoroughly inspect all mural panels for defects.
- VERIFY all wall and product measurements.
- CHECK walls for bowing, sagging or uneven surfaces as these may cause panels to misalign.
- STOP immediately and contact your representative if any discrepancy is discovered.

While this product is warranted against all manufacturing defects, 4walls.com cannot be responsible for improper installation or problems arising from defects in the construction, surface, or preparation of the wall. See reverse for complete warranty information.

NOTE: Murals & Accent Murals are shipped with unprinted selvage around the all edges that requires trimming during installation.

wall preparation

Borders & Cut-Outs may be applied to any dry, clean, smooth surface. Old wallpaper or other surface materials should be removed before application.

Fill cracks with a spackling compound or plaster patching and sand to a smooth surface. Glossy or enamel finish walls should be lightly sanded, then washed with a common household detergent and then allowed to dry completely. Any greasy surface should be cleaned with a strong ammonia solution and then allowed to dry completely.

For drywall preparation countersink all nail heads. Tape or repair all joints or holes using joint tape or a wall patch and joint compound and then let dry. Sand the wall to a smooth finish.

Prime all new drywall with a wallpaper primer/sealer and follow primer instructions for the dry time (normally 24 hours).

We recommend that you apply your border directly to a prepared wall surface, not to the surface of underlying wallpaper.

avoiding show-through

If the walls to be covered have highly contrasted colors or white patches on dark wall, prime over the contrasting areas until the entire area has a uniform color.

dealing with mold or mildew

Any area with mold or mildew should also be prepared before application. Wash any mold or mildew areas with chlorine bleach (1cup Clorox® to 3 quarts water). Rinse clean and then let dry.

before you apply wallcovering

Extreme caution should be used when trimming or hanging wallcovering around electrical outlets. Turn off ALL electrical current to room at the fuse or circuit box.

tools you may need

sturdy step stool or stepladder
razor blade knife and extra blades
tape measure
level or plumb bob
yardstick or straight edge

clean sponge or soft cloth
clean water and a water tray
drop cloth
large plastic trash bags



border application

To activate the paste, use a 3/8" nap roller to roll lukewarm water on the back (unprinted) side of the border. Or, roll up the length of the border loosely (pattern inward) and soak for 10 seconds in a water tray 3/4 full of lukewarm water. Remove carefully from the water tray, allowing the excess water to drain into the tray.

"Book" the border by folding it without creasing it, pasted side to pasted side (bring in both edges toward the middle), for 3 to 5 minutes.

Begin in the room's most hidden corner (behind the door, for example), and smooth the border in place with a sponge. Use your sponge and clean water to wipe clean the border and surrounding wall area. Install remaining border sections using the same procedure, taking care to match the pattern. When you reach an outside corner, simply wrap the border around it. When you reach an inside corner, simply press the border firmly into the corner with a soft cloth or wallpaper brush to adhere it smoothly to each wall and snugly in the corner. Be sure to press the border firmly into the corner and against each wall to prevent it from pulling away from the wall as it dries.

Wallcovering is very strong when wet; however we recommend that you do not apply a great deal of side-to-side pressure when applying the material. We also recommend using a "smoothing" brush to remove air pockets or paste lumps. Work air pockets or paste outward toward the edges. If you are using a squeegee, always use a plastic blade instead of a metal blade as metal may tear through the material or damage the printed surface.

Trim your border with a clean, single edge razor blade or a sharp pair of scissors.

cut-out application

Trim around the perimeter of each cut-out using a clean, single edge razor blade or a sharp pair of scissors.

To activate the paste, use a 3/8" nap roller to roll lukewarm water on the back (unprinted) side of the cut-out. Or, soak it for 10 seconds in a water tray 3/4 full of lukewarm water. Remove carefully from the water tray, allowing the excess water to drain into the tray.

Position the cut-out on the wall and smooth it in place with a sponge. Use your sponge and clean water to wipe clean the cut-out and surrounding wall area. Be sure to press the cut-out firmly into place to prevent it from pulling away from the wall as it dries. Work air pockets or paste outward toward the edges. If you are using a squeegee, always use a plastic blade instead of a metal blade as metal may tear through the material or damage the printed surface.

cleaning your wallcovering

Sponge-clean your wallcovering. Use a lukewarm, mild detergent solution. Do not use abrasive cleaners containing chlorine bleach, solvents, or ammonia as they may attack and damage the printed surface.

****Caution****

**Plastic bag may be
a choking hazard
KEEP AWAY FROM SMALL
CHILDREN**



surrounddecor

4700 Lakeside Avenue
Third Floor
Cleveland, Ohio 44114
1-800-496-4444

sales@surrounddecor.com

Limited Warranty: *The manufacturer warrants that for a period of two (2) years from the date of shipment that its wallcovering products will conform to their product specifications and will be free from defects in excess of those permitted by their product specifications. THE MANUFACTURER DISCLAIMS ALL OTHER REPRESENTATIONS AND WARRANTIES, EXPRESS OR IMPLIED. INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If any product sold by manufacturer fails to conform to the above warranty, manufacturer shall supply replacement product free of charge. The supply of replacement product is the exclusive remedy and is the limit of the manufacturer's liability. In no event shall the manufacturer be liable for incidental or consequential damages.*

designed & manufactured in the U.S.A.

• all designs and content © DLM Studio